

Cartridge Refilling Instructions

For 160R2, 160DT, and 160AN Air Purifiers

While the E.L. Foust Co., Inc. recommends that customers purchase refill cartridges from us, you may choose to purchase loose media and fill your own air filter cartridge.

WARNING: THERE WILL BE DUST WHEN YOU EMPTY AND FILL THE CARTRIDGE. DO NOT ALLOW DUST FROM **USED OR NEW** CARBON MEDIA TO REST ON ANY SURFACES AS DAMAGE MAY RESULT. IT MAY SCRATCH SURFACES. DO NOT ALLOW CARBON OR CARBON DUST TO COME IN CONTACT WITH DAMPNESS OR WATER AS DAMAGE TO SURFACES MAY RESULT. THE E.L. FOUST CO., INC. ACCEPTS **NO LIABILITY OR RESPONSIBILITY** FROM ANY DAMAGE THAT MAY RESULT FROM CUSTOMERS WISHING TO REFILL THEIR OWN CARTRIDGES. USE PROTECTIVE COVERING ON IMPORTANT ITEMS THAT MAY BECOME DAMAGED, BE SURE TO HAVE GOOD VENTILATION!
IT'S RECCOMENDED THIS BE DONE OUTDOORS OR IN A GARAGE.

1. Remove the handle or wing nut at the base of your unit.
2. Remove the round base plate.
3. Carefully lift the cylindrical cartridge out from the motor-housing assembly.
4. Remove the wires/spring steel inside the cartridge which fasten the pink particulate filter or HEPA filter. These wires/spring steel are under tension and they may spring out. Care is ad-

HEPA Filter: These wires/spring steel are under tension and they may spring out. Care is advised. Remove the pink particulate filter (Filterdown) or HEPA filter, detach it from its screen, attach new Filterdown to screen.

5. Remove the fiber tape from the cartridge and lift off the silver end cap.
6. Dispose of the used media and vacuum all parts before refilling.
7. Refill the cartridge with fresh media using a funnel or another appropriate device, taking care to tap the side of the cartridge firmly as you fill in order to assure that the media is packed tightly and densely. If air spaces are present, air intake through the cartridge will be uneven and improper purification will result. After you have filled the cartridge, raise the entire cartridge and tap its bottom on the floor to settle the media. If more space forms at the top after tapping, top it off with more media until filled to the rim.
8. Replace the silver end cap and secure with tape.
9. Insert the new pink particulate filter or HEPA filter and fasten with spring steel.
10. Reassemble the cartridge between the motor-housing and base.

NOTE: You will need approximately 7 pounds of carbon to fill your #160R2 cartridge, and approximately 3 pounds to fill either the #160DT or #160AN.

If you specify that you are buying carbon to fill our units, you will receive the pink particulate filter (Filterdown) at no charge, or the optional HEPA filter for an additional \$25.

There is no shipping charge in the continental US!

Call: 1-800-353-6878 **E-Mail:** sales@foustco.com **Visit Us On The Web:** www.foustco.com